

STEW MEYERS' FREE-WHEEL

The photo below is more or less self-explanatory. Take a wheel collar, file a notch in it and solder a short piece of brass tubing and insert the wire bent as shown below. Works equally well with a wooden prop.

